

VMS WEB STUDIO[®] User Manual

Version 4.1.0

BARTCO Traffic Equipment Pty. Ltd.
7 Westside Ave, Port Melbourne, VIC 3207, Australia.
Phone: +61 3 9646 8580 / 1300 306 106
Website: www.bartco.com.au
Email: service@bartco.com.au

Contents

Introducing Bartco VMS Web Studio®	2
1. Logging In	3
2. Web Studio Main Page Orientation	4
3. Assets, Groups and Job Queue	5
3.1 Assets	5
3.1.1 Asset's icon and status icons	6
3.1.2 Filters	8
3.1.3 Quick options menu	10
3.2 Groups	11
3.3 Job Queue	14
4. Asset Information	15
4.1 Asset Status	15
4.2 Asset Info	17
5. Update Status	18
6. Mapping	19
7. Create Message	20
7.1 Predefined Images	21
7.2 Message Transitions/Animations	22
7.3 Preview	24
8. Uploading file to asset	25
8.1 Save File	25
8.2 Open File	26
8.3 Upload saved file to asset	27
8.4 Upload file without saving	28
9. Quick Speed	29
10. Radar	31
11. SMS & Security	35
12. Scheduler	38
12.1 Create Schedule	38
12.2 Schedule a radar file	43
13. File Manager and Uploading Multiple Files	44
14. Hire Management	48
14.1 Add Hire Customer	49
14.2 Add User(s) to Hire Customer	50
14.3 Add Asset(s) to Hire Customer	51
15. Troubleshooting	52


Introducing Bartco VMS Web Studio®

BARTCO VMS WEB STUDIO® is a web-based application that runs on BARTCO's secure cloud network for maximum security and high availability. It has been developed to allow customers to interact and provide full management of their BARTCO products, including Variable Message Signs (VMS), Variable Speed Limit Signs (VLS), Electronic Fire Danger Rating signs, Electronic Snow / Wheel Chain Rating signs and Portable Traffic Signals, etc.

VMS WEB STUDIO® is a real-time internet-based communication facility enabling live communication via cellular or satellite networks from any internet enabled PC, laptop, tablet or mobile, eliminating the need for the installation of local software.

Features include:

- Fully web based allowing remote programming from any internet enabled PC / Laptop / Tablet or mobile.
- Secure login
- Asset Management and tracking system
- Create and manage customers (perfect for hire/rental companies)
- Quick and easy operation
- Clean user-friendly interface
- Asset grouping
- Program multiple assets instantly



1. Logging In

From the browser address bar go to the VMS Web Studio web page: www.vmsstudio.com

Enter your username and password as received in your email.

Notes:

- If you have not been allocated a username and password, please contact Bartco to receive a user access form.
- Contact Bartco to delete a user from Web Studio
- Bartco suggests using Google Chrome as the best compatible browser with Web Studio. Google Chrome can be downloaded at the link: <http://www.google.com/chrome>

BARTCO
Visual Information Systems

PH: 1300 306 106 | +61 3 9646 8580

VMS WEB STUDIO®

New **BartcoLive®** App
Message Creation
Greater Flexibility

Download on the App Store

GET IT ON Google Play

Read More

Welcome to Bartco VMS WEB STUDIO®

VMS WEB STUDIO® is the world's leading VMS programming and management interface

Login to the Bartco Portal...

Email or Username:

Password:

Login

Forgot your password [Click Here](#)

2. Web Studio Main Page Orientation

The screenshot shows the VMS WEB STUDIO v1.60.0 interface. The top navigation bar includes the BARTCO logo, contact information (PH: 1300 306 106 | +61 3 9646 8580), the product name VMS WEB STUDIO®, and a 'Welcome Bartco' message with a 'Report...' button and a 'Logout' button. Below the navigation bar is a toolbar with icons for Dashboard, Mapping, New File, Quick Speed, Radar, Scheduler, and SMS & Secu. The main dashboard area contains several widgets: 'Communication' and 'Battery' status indicators with donut charts and counts; 'Assets on Hire' and 'Assets by Type' charts; and an 'Assets' list on the right. The 'Assets' list shows various custom groups like '#VLS 1', 'Bartco test board', 'Bench Testing 1', 'Bench Testing 3', and 'Fire Sign DEMO 1'. An 'Asset Information' panel on the right provides detailed data for a selected asset, including Name, Date, Time, Firmware version, Serial number, Active File, Active Status, Battery voltage, Temperature, Cooling Fans, LED Output, Trip Wire, and Luminance. An 'Information' panel at the bottom displays a welcome message and version information.

Dashboard provides helpful insights on assets

Real time asset's location on map

Feature / Tool tabs: Each tab represents a different operational feature

Asset list: List of all assets that user has access to.

Information panel: displays result of an action on asset

Details on asset's status like battery, active file, luminance, etc.

3. Assets, Groups and Job Queue

3.1 Assets

All the assets are displayed in the Assets List.

The screenshot shows the 'Assets' window with the following callouts:


- Filter assets by name, type, group, etc.**: Points to the 'Groups / Filter' dropdown menu.
- Search asset by name, serial number,**: Points to the search input field.
- Various filters applied to assets**: Points to the 'Group: 1 x' filter chip.
- Asset icon: type of the asset**: Points to the icon of the 'Bartco test board' asset.
- Status icons: legends described below**: Points to the row of status icons for the 'Bartco test board' asset.
- Asset name**: Points to the text '#VLS 1 Custom group'.
- User defined Group name**: Points to the text 'Bartco test board Custom group'.
- Select all assets, select none, invert selection**: Points to the 'All', 'None', and 'Invert' buttons at the bottom.
- Number of selected assets**: Points to the '0' in the '0 / 5' indicator.
- Total number of assets in list**: Points to the '5' in the '0 / 5' indicator.

3.1.1 Asset's icon and status icons

Asset's icon represents type of the asset:

	5 Colour A Size		Amber A Size
	5 Colour B Size		Amber B Size
	5 Colour C Size		Amber C Size
	Portable Traffic Light - Master		Fire Sign 4 Ratings
	Portable Traffic Light – Slave		Retrofitted Fire Sign
	VSL (Variable Speed Limit Sign)		HDA sign
	Half Size - Speed Sign		HDC sign
			Wide Size Sign

Asset shows several status icons to denote various state of an asset as described below:



-  Status older than 24 hours
-  Asset has communicated in last 24 hour and has warning
-  Asset has communicated in last 24 hour

-  Battery Low (warning)
-  Battery OK
-  Battery Good

-  Low signal strength (warning)
-  Weak signal strength
-  Strong signal strength

-  Locked by Web Studio
-  Automatic programming enabled
-  Automatic programming disabled

-  Firmware critically out of date (warning)
-  Latest firmware installed

 Radar enabled

 Radar disabled

 Locked by Road Authority

 Not locked by Road Authority

 Satellite enabled

 Satellite disabled

 Asset is currently on hire to HIRE-CUSTOMER-NAME

 Asset is hired to HIRE-CUSTOMER-NAME and hire duration is inactive


 Asset is available to hire

 No permission to hire asset

3.1.2 Filters


Filter assets by Alert, Controller Config, asset type, etc.

Assets by Alert menu shows below alerts:




Alert Description	Count
Status older than 24 hours	12
Asset has communicated in last 24 hours and has warning	1
Asset has communicated in last 24 hours	4
Battery Low	4
Battery OK	0
Low signal strength	0
Weak signal strength	5
Firmware critically out of date	0
Radar Enabled	1
Automatic programming enabled	0
Locked by WebStudio	2
Locked by Roding Authority	0
Satellite enabled	0
Assets currently on hire	0
Assets currently on hire and duration is inactive	1
No permission to hire asset	0

Controller Config menu shows below options:



Various filters can be applied simultaneously to the assets list.

For example, filter all assets that are currently on hire 🚚 and has low battery 🔋:



3.1.3 Quick options menu

Right click on selected asset in the Assets list to display quick options menu.

Note: this menu changes based on asset’s type.

The following is an example of quick options menu on VMS:




- i. Update status
Manually update the status of asset
- ii. Blank sign
Blank the display of asset
- iii. Wake sign
Start displaying last message on the asset
- iv. Sleep sign
Put asset in sleep mode
- v. Program History
Show history of messages programmed on the asset


Program History: 02 Jul 2021 12:23 PM					
	Preview	Name	Type	Uploaded By	Uploaded Date
1		bartco logo	bart2	[REDACTED]	02/07/2021 11:43 am

3.2 Groups

Very useful if you have multiple assets in your account. Assets can be grouped by one project, area, or section of roadway using user defined group name.



Selecting a group will list all the assets in that group:



➤ **Group an asset using Asset Info:**

- i. Select asset from Assets list
- ii. Go to Asset Info
- iii. Update value of the “Group” field

Asset Information

Bartco test board 2

Bartco testing


Asset Status

Asset Info


Name	Value
Company	Bartco
Asset ID	187371
Model / Plant type	VMS 400 5 Colour
Controller Serial	A018THS104
Trailer VIN	tab
Trailer Registration	tab
Trailer Serial	
Special Features	
Firmware Version	1.5.24VHE
Hardware Version	Issue 8 F
Label	Bartco test board 2
SIM PIN	
Client Ref	123
Trailer Key	
Group	Bartco testing

➤ **Group an asset using Groups/Filter:**

- i. Select asset from Assets list
- ii. Select **Groups / Filter**




- iii. Select "Move to" or "Move to new Group" option from Selected Assets menu



3.3 Job Queue

Upload file, updating status, etc. tasks are added in the Job Queue. When the job is completed successfully, it will be removed from the Job Queue. If there is an error in completing the job, then the error is displayed in the Job Queue.




4. Asset Information

Click on an asset to see its detailed status.

4.1 Asset Status


The fields in the status changes based on the asset type. The below is an example of VMS:



Date	Last date when asset communicated with Web Studio
Time	Last time when asset communicated with Web Studio
Firmware version	Firmware version of the asset
Serial number	Serial number of the asset
Active File	Asset is currently displaying this file
Active Status	State of the asset

Battery voltage	Battery of the asset
Temperature	Temperature of the controller in centigrade
Cooling Fans	Cooling fans are active or inactive
LED Output	Brightness of the display in percentage
Luminance	Shows level of luminance and Auto or Manual mode
Trip Wire	Tamper Alarm loop The name of this field can be set using "Input 1 Label" in Asset Info. Default value is "Trip Wire"
Radar	Radar is enabled/disabled on the asset
GPS Lat	GPS latitude of the asset
GPS Long	GPS longitude of the asset
Global ON:OFF Time	Global time to switch the display on/off
Signal Strength	Signal strength of the asset
Files	List of files stored on the asset

4.2 Asset Info



Asset Information

Bartco test board
Custom group

Name	Value
Company	Bartco
Asset ID	174433
Model / Plant type	VMS 400 Amber
Label	Bartco test board
Client Ref	abcd-1
Group	Custom group
Trailer VIN	TBD
Trailer Registration	TBD
Trailer Serial	
Controller Config	
Serial number	A016THS328
Hardware	Issue 8 F
Firmware	1.5.24VGE
Input 1 Label	Trip Wire
Radar Fitted	NO
Special Features	
Trailer Key	
SIM PIN	


Value of these fields can be edited by the user

Company	Owner company of the asset
Asset ID	Unique identified of the asset
Model / Plant type	Asset type
Label	Name of the asset (editable by user)
Client Ref	Another name of the asset (editable by user)
Group	Group of the asset (editable by user)
Trailer VIN	VIN number of the asset's trailer
Trailer Registration	Rego number of the asset's trailer
Trailer Serial	Serial number of the asset's trailer
Serial number	Serial number of the asset
Hardware Version	Hardware version of the asset
Firmware Version	Firmware version of the asset
Input 1 Label	Label for Input 1 on the controller (editable by user)
Radar Fitted	Radar is fitted on the asset (editable by user)
Special Features	Any special characteristics of the asset, such as 4G
Trailer Key	Trailer key of the asset (editable by user)
SIM PIN	Sim card PIN number (if applicable)


5. Update Status

To update the status of an asset:


- i. Select asset(s) from the Assets list
- ii. Right click on selected asset(s)



- iii. The user will be prompted as follows:




- iv. Click on OK to update status of the selected asset(s). The job will appear in Job Queue. Click on Cancel button to cancel uploading.




On completion, the result will be displayed in the Information panel at the bottom of the page.

Success:




Failed:



6. Mapping

Bartco’s assets have inbuilt tracking system. This is used to display location of assets on maps. The location of the asset is the last known location of asset when it communicated with Web Studio.




The screenshot shows the 'Mapping' tab in the VMS Web Studio interface. It features a Google Maps view of Melbourne, Australia, with a 'Bartco test board' asset marker. A pop-up window for the asset displays its status: Voltage: 13.5 V, Temperature: 28°C, and Trip Wire: ALARM!. A black box with the text 'Display Blanked' is overlaid on the pop-up. Below the map, four callout boxes provide instructions:

- Directions to my asset:** Get directions to your asset from a given address
- Print Map:** Print map view
- Measure Distance:** Measure distance between points
- Assets Panel:** Double click on asset to get a close-up of the asset location


7. Create Message

Creating a message is undertaken by selecting the “New File” tab from the main navigation page. This tab is also known as Drawing Area which creates Standard file. Once the message is prepared and saved under a name then that name will appear on the tab instead of new file/untitled.




Draw or type your desired message in the drawing area. The drawing area is scaled to be the same size as the asset (VMS, Fire sign, etc.).

The message can be typed in colour by selecting the required colour from the Drawing Tools. Different font sizes and line alignments are also available to choose.



Various functions on the frame can be performed using the below menu:



Multiple frames can be created with different frame time. Use paging button to navigates through the frames.




Frame timing can start at 0.1 of a second to create animations. Length of message, asset position and target audience should all be considered when selecting frame times.

7.1 Predefined Images

Several predefined images are available like speeds, land closure, etc. which can be loaded directly onto the frame to prepare a message.

➤ To load a predefined image:

- i. Select image from the predefined images list
- ii. Click on “Load >>” button
Predefined image will be loaded in frame on the drawing area



7.2 Message Transitions/Animations


More commonly VMS are being used for advertising and promotions. Web Studio has the ability to create dynamic and animated messages to enhance the appeal of your message.

To create a message transition or animation, simply create your message and then click on the Frame Organizer button from the menu.




➤ **To apply transition/animation to your message:**


- i. Click on desired frame to be animated in Frame Organizer
- ii. Select transition/animation from the dropdown



- iii. Select side




- iv. Set frames per second
Note: higher the frame per second, lower the speed of the animation and more the number of frames in transition.
- v. Click on Apply button
The selected frame will display the preview of the transition



- vi. After finishing applying transitions to desired frames, click on OK to save the changes and close the Frame Organizer

7.3 Preview

Check the preview of the message to see how it will look on the VMS:



Preview of the message:




8. Uploading file to asset


Once the file has been prepared, it can either be saved or directly uploaded to the asset. To use messages in Radar and/or Schedule, it needs to be saved first. The message is saved in the cloud and is accessible to all the users of your company using their Web Studio account.

8.1 Save File

- i. Go to File -> Save As




- ii. Enter filename and click on Save As button to save the file




8.2 Open File

- i. Go to File -> Open



- ii. Select file from the list and click on Open button




8.3 Upload saved file to asset


- i. After your file has been saved/opened, select asset(s) from the Asset list that you wish to upload the message to.
 Note: Multiple assets can be programmed simultaneously by holding down the shift or Ctrl key on your keyboard when selecting asset(s).

- ii. Click on Upload button .
 The file that is open in the tab will be uploaded to the selected asset.

- iii. The user will be prompted as follows:




- iv. Click on YES to upload file to the selected asset(s). The job will appear in Job Queue. Click on NO to cancel uploading.



On completion, the result will be displayed in the Information panel at the bottom of the page.

Success:



Failed:



Note: After you have uploaded your message, the active file will update with your current message and the overall asset status.

8.4 Upload file without saving

Messages can be uploaded without saving them first.

- i. After your desired message is prepared, select asset from the Asset list that you wish to upload the message to.
 Note: Multiple assets can be programmed simultaneously by holding down the shift or Ctrl key on your keyboard when selecting asset(s).


- ii. Click on Upload button 

The message will be automatically saved into your __Unsaved_Files folder.

Notes:

- Files in this folder can be opened and resaved into another folder.
- Files cannot be manually saved into this folder.
- Files cannot be moved in or out of this folder with the File Manager.

- iii. The user will be prompted as follows to remind that an unsaved file is being uploaded:




- iv. Click on YES to upload file to the selected asset(s). The job will appear in Job Queue. Click on NO to cancel uploading.




On completion, the result will be displayed in the Information panel at the bottom of the page.

Success:



Failed:




Note: After you have uploaded your message, the active file will update with your current message and the overall asset status.

9. Quick Speed


Quick speed is designed to quickly change speed limits on VMS or VLS assets.

➤ **To change the speed:**


- i. Select speed from the dropdown list
- ii. Select asset(s) from the Assets list
- iii. Click on “Upload” on Quick Speed tab



- iv. The user will be prompted as follows:



- v. Click on OK to upload speed to the selected asset(s). The job will appear in Job Queue. Click on Cancel button to cancel uploading.



On completion, the result will be displayed in the Information panel at the bottom of the page.

Success:

Information



Speed: 40 Flash
Asset: BARTCO test board (174433)
Job Complete
Speed updated to 40 Flash

Failed:

Information



Speed: 40 Flash
Asset: BARTCO test board (174433)
Cannot connect to asset

10. Radar

Any Bartco VMS asset can become a speed advisory sign provided the asset is fitted with a Radar.


The Radar can be programmed in two ways depending on the requirement:

- Option 1: Display the detected speed only
The asset typically stays in off mode and starts displaying the speed of the vehicle upon detection then go to sleep again. On top of detecting the speed of the approaching vehicle, the user can also set up an advisory message if the road user is going above the specified speed limit or below the speed limit.
- Option 2: Interrupt displayed message
Instead of going to sleep/off the asset can show a standard message or speed limit message when no vehicle is present. In this instance, the standard message needs to be uploaded to the asset separately to the radar file.

The Radar feature is accessible under the “Tools” menu:



Radar feature will be displayed as follows:



Activate the Radar:

What would you like your asset to do

Display the detected speed only

Interrupt displayed message

Message displayed during Radar mode

First: Speed Large

Time to display first (sec): 0

Custom text in first line Note: Custom text is only available in firmware version 1.5.24

70 km/h

Second: Nothing

Time to display second (sec): 0

Posted Speed Zone (km/h): 50

Minimum detection / display speed (km/h): 20

Maximum detection / display speed (km/h): 20

Radar Default File (Scheduler only): Radar Default File

Select File

Data Logging Options

Enable Logging

Minimum logging speed (km/h): 10


Update Interval (sec): 1

Log Settings... Download Radar Logs... Disable Radar UPLOAD



Two actions can be executed on the asset after the radar detects approaching vehicle.

The first action on the asset can be set to any of the following:



- i. **Speed**
Asset shows the detected vehicle speed only, it can be shown in 2 different formats.
Example: speed can be shown as 70 km/h or just 70 (tick Large checkbox for this)
- ii. **Radar High/Low**
In this option the user can upload 2 files (Such as “TOO FAST” for speeding and THANK YOU for doing below the speed limit) that can advise the speeding vehicle that they are doing over the speed limit or doing below the speed limit without showing the vehicle speed.
- iii. **Radar High**
In this option the user can only upload 1 file that can advise the speeding vehicle if the vehicle is approaching above the speed limit to say SLOW DOWN or TOO FAST. If the vehicle is doing below the speed limit, then the asset will not respond to them.
- iv. **Radar Low**
In this option the user can only upload 1 file that can advise the speeding vehicle if the vehicle is approaching below the speed limit to say THANK YOU. If the vehicle is doing above the speed limit, then the asset will not respond to them.

The second action on the asset can be set as follows:

If the first action of the asset is to show the vehicle speed and follow it up with advisory message, then the user needs to select SPEED option in the first option and RADAR HIGH/LOW in second option.



Note: The files such as TOO FAST, SLOW DOWN or THANK YOU needs to be prepared first as described in section [7. Create Message](#) and save the files as described in section [8.1 Save File](#)

The so-called over speed and under speed threshold can be set up at the “Posted Speed Zone” Minimum and maximum detection speed limits can also be setup on the asset to prevent it to be abused.

Note: the asset will not respond if the detected speed of the approaching vehicle is outside of the minimum and maximum detection range. However, the logs will record the speed of every vehicle.

Posted Speed Zone (km/h) :	<input type="text" value="50"/>	⬆️⬇️⬆️
Minimum detection / display speed (km/h) :	<input type="text" value="20"/>	⬆️⬇️⬆️
Maximum detection / display speed (km/h) :	<input type="text" value="20"/>	⬆️⬇️⬆️

The user can also schedule a radar that can turn on/off at certain times of the day. Radar default file can be used if a message needs to be displayed on the asset during the scheduled radar times.

Note: Radar default file will only work if the radar file is scheduled. For example, see section [12.2 Schedule a radar file](#).

Radar Default File (Scheduler only) :	<input type="text" value="Radar Default File"/>	<div style="border: 2px solid yellow; background-color: black; color: white; padding: 10px; display: inline-block;">Select File</div>
---------------------------------------	---	--

Enable data logging to record detected speed of the vehicle with a timestamp. Radar logs can be downloaded manually or set up to be emailed daily.

Data Logging Options		
Enable Logging	<input type="checkbox"/>	
Minimum logging speed (km/h) :	<input type="text" value="10"/>	⬆️⬇️⬆️
Update Interval (sec) :	<input type="text" value="1"/>	⬆️⬇️⬆️

➤ **Upload radar to asset**

i. Save file if required for later use as described in section [8.1 Save File](#)
 Note: Radar files are saved as different file types than standard files. You may wish to have a separate folder for your radar config.


ii. Select asset(s) in Assets list

iii. Click on Upload button  at bottom of the Radar tab
 Radar config that is open in the Radar tab will be uploaded to the selected asset.

iv. The user will be prompted as follows:




v. Click on YES to upload file to the selected asset(s). The job will appear in Job Queue. Click on NO to cancel uploading.




On completion, the result will be displayed in the Information panel at the bottom of the page.

Success:



Failed:



11. SMS & Security

Your asset is equipped with security and operational features which means the asset can send an SMS to the operator/s if the unit is tampered with, stolen or if there are any voltage issues.

From the Tools menu select SMS:



The following SMS options can be set:

The screenshot shows the 'SMS & Security' configuration page. It is divided into three main sections: 'Alarms', 'Mobile Phone Numbers', and 'Reporting Interval'. Callout boxes provide additional context for several elements:

- Alarms Section:**
 - A callout box points to the 'Alarms' section header, stating: "Various alarms to be set on asset".
 - Buttons for 'Select All', 'Select None', and 'Clear All' are visible.
 - A note states: "Note: Traffic Light controllers only support Under Voltage".
 - Settings include:
 - Over Voltage: 14.5 Vdc
 - Under Voltage: 11 Vdc (checked)
 - Over Temperature: 75 °C
 - GPS Movement: 500 metres
 - Tamper Enabled (unchecked)
 - Blank display (unchecked)
 - Blank display on VMS. Flash amber on Traffic Light controllers (checked)
- Mobile Phone Numbers Section:**
 - A callout box points to the 'Mobile Phone Numbers' section header, stating: "Set mobile numbers to which SMS is sent by asset".
 - Fields for 'Mobile number:' and 'Phone Number' are present, with 'No mobile numbers' displayed below.
 - 'Add' and 'Delete' buttons are at the bottom.
- Reporting Interval Section:**
 - A callout box points to the 'Reporting Interval' section header, stating: "Reporting interval for alarms".
 - The 'Reporting Interval' is set to 60 minutes.
- Upload Button:**
 - A callout box points to the 'Upload' button (with an upward arrow icon), stating: "Upload SMS config file to asset".

Select your options as required, following are suggested settings:

- Over voltage: recommended at 14.5 V
 - Under voltage: recommended at 11.0 V
 - Over Temperature: usually not required
 - GPS movement: recommended at 1000 m
- Note: Ensure that you either upload this option after the asset has been deployed to its desired location or the asset is set to sleep prior to moving.
- Tamper Enabled: Anti tamper wire where it is fitted

After your options are selected, input up to 3 mobile phone numbers that will be alerted if any of the alerts are activated.

The screenshot shows two sections of the VMS WEB STUDIO interface. The first section is titled 'Mobile Phone Numbers' and contains a text input field labeled 'Mobile number:' with a 'Phone Number' button to its right. Below the input field are 'Add' and 'Delete' buttons. The second section is titled 'Reporting Interval' and contains a text input field labeled 'Reporting Interval:' with a dropdown menu showing '60' and the word 'minutes' to its right.

To remove SMS settings simply uncheck all the boxes and upload file to the asset.

We suggest saving your active and inactive SMS settings in separate folders for consistency and future use.


➤ **Upload SMS config to asset**

i. Save file if required for later use as described in section [8.1 Save File](#)
 Note: SMS files are saved as different file types than standard files. You may wish to have a separate folder for your SMS config.


ii. Select asset(s) in Assets list

iii. Click on Upload button  at bottom of the SMS & Security tab
 SMS config that is open in the SMS & Security tab will be uploaded to the selected asset.

iv. The user will be prompted as follows:




v. Click on YES to upload file to the selected asset(s). The job will appear in Job Queue. Click on NO to cancel uploading.




On completion, the result will be displayed in the Information panel at the bottom of the page.

Success:



Failed:



12. Scheduler

Your VMS comes standard with a GPS module which allows the VMS to keep time as well as the ability to schedule messages as required, instead of uploading messages each time.

Perfect for Roadworks applications where there may be a pre-warning message, and a message to be displayed once the Roadworks begin.


12.1 Create Schedule

To Schedule a file, the desired messages need to be created first as described in section [7. Create Message](#) and save those messages as described in section [8.1 Save Message](#)

The Scheduler feature is accessible under the “Tools” menu:




Scheduler feature will be displayed as follows:




Default file: the default file is displayed when the other scheduled messages are not operating. If no default message is selected, then the asset will be blanked when the other scheduled messages are not operating.

➤ **Select a default file:**

- i. Click on Default File button
- ii. Select a file from File Dialog and click Open




- iii. Default file will be selected, and its preview displayed as below:




➤ **Schedule a message:**


- i. Click on “Add Message” button




- ii. Click on “Select File” button
- iii. Select a file from File Dialog and click Open



- iv. A file will be selected, and its preview displayed as below. Other options will now be enabled



- v. Set date and time for the selected message to run as part of schedule



- vi. Click on "Insert" button to add this message to the list

Scheduled Files										
<input type="checkbox"/> Enable Grouping <input type="checkbox"/> Edit Schedule <input type="checkbox"/> Delete Schedule(s) <input type="checkbox"/> Copy Schedule(s)										
	Edit	Delete	Preview	Filename	Continuous	Start Date	End Date	Start Time	End Time	Days
1				R-ahead	NO	01/12/2021	10/12/2021	09 : 00	18 : 00	All

The message R-ahead will now run from 01/12/2021 to 10/12/2021 from 9am to 6pm every day. Outside these times, the default message will be displayed.

Note: If the Continuous box is checked then the message will run from 9am on 01/12/2021 until 6pm on 10/12/2021 as a continuously running message.


If you would like any other messages to be scheduled simply repeat the process above.

➤ **Upload schedule to asset**


- i. Save file if required for later use as described in section [8.1 Save File](#)
Note: Scheduled files are saved as different file types than standard files. You may wish to have a separate folder for your schedules.
- ii. Select asset(s) in Assets list

- iii. Click on Upload button  at bottom of the Scheduler tab
Schedule that is open in the Scheduler tab will be uploaded to the selected asset.

- iv. The user will be prompted as follows:




- v. Click on YES to upload file to the selected asset(s). The job will appear in Job Queue. Click on NO to cancel uploading.




On completion, the result will be displayed in the Information panel at the bottom of the page.

Success:



Failed:



12.2 Schedule a radar file

Example of scheduling a radar file:

A VMS asset is placed in school zone that normally shows the speed limit 60 and changes the speed limit to 40 between 8:00am to 9:30am with radar that shows “SLOW DOWN” if the vehicle goes over the speed limit of 40.

In this case the radar file will be created with the following:

Activate the Radar:

What would you like your asset to do

Display the detected speed only

Interrupt displayed message

Message displayed during Radar mode

First: Speed
 Time to display first (sec):

Large
 Custom text in first line
Note: Custom text is only available in firmware version 1.5.24



Second: Radar High
 Time to display second (sec):

Radar High File: slowdown



Posted Speed Zone (km/h):

Minimum detection / display speed (km/h):

Maximum detection / display speed (km/h):

Radar Default File (Scheduler only):




Data Logging Options

Enable Logging

Minimum logging speed (km/h):

Update Interval (sec):

Once the radar file is ready then the schedule will be prepared with the current radar file between 8:00am to 9:30am with a default file that shows the speed limit 60.




The screenshot shows the VMS Web Studio Scheduler interface. At the top, there are browser tabs for Home, Mapping, 40FLASH, Quick Speed, Radar - 40km, and Scheduler. The main content area shows a default file of 60FLASH with a speed limit sign image and an 'Add Message' button. Below this is a 'Scheduled Files' section with a table of scheduled events.

Filename	Continuous	Start Date	End Date	Start Time	End Time	Days
40km_radar	NO	01/03/2021	31/03/2021	08 : 00	09 : 30	Monday, Tuesday, Wednesday, Thursday, Friday

13. File Manager and Uploading Multiple Files

Multiple messages or options to your asset can be uploaded directly from File Manager



File Manager displays list of files and folders.


The File Manager interface is shown with several callouts explaining actions:

- Create New Folder:** Points to the 'New Folder' button in the toolbar.
- Open file or folder:** Points to the 'Open' button in the toolbar.
- Rename selected file or folder:** Points to the 'Rename' button in the toolbar.
- Delete selected file or folder:** Points to the 'Delete' button in the toolbar.
- File's details:** Points to the 'Details' button in the toolbar.
- Rename: rename file or folder:** Points to the 'Rename' icon in the file list.
- Delete: delete file or folder:** Points to the 'Delete' icon in the file list.
- Upload multiple files:** Points to the 'Upload Files' button at the bottom right.


	Rename	Delete	Preview	Name	Type	Date Created	Created By
1				Testing folder	File Folder	02/07/2021 03:00 pm	its_demo
2				__Unsaved_Files	File Folder	01/07/2015 10:57 am	dolly
3				Speed_10	bart2	14/02/2020 10:15 am	its_demo
4				test1	bart2	02/07/2021 03:00 pm	its_demo
5				test2	bart2	02/07/2021 03:00 pm	its_demo

➤ **To upload file(s) from File Manager:**


- i. Click on Upload Files
The following dialog will be displayed:




- ii. Click on Add File and select type of file (Standard, Radar, etc.) or function (Blank sign, etc.)




- iii. For type of file, select file(s) from file dialog
Select a file and click on “Select File” button




- iv. Once all the files have been listed, select asset(s) in Assets list and click on “Upload” button



- v. The user will be prompted as follows:




- vi. Click on YES to upload files to the selected asset(s). The job will appear in Job Queue. Click on NO to cancel uploading.




On completion, the result will be displayed in the Information panel at the bottom of the page.

Success:



Failed:




14. Hire Management

A significant feature of Bartco’s Web Studio is for hire companies or other general users to be able to provide their own customer or user with a login and access to asset(s).

Customers can be given access to the system for a determined period, relative to their hire period. Once the customer has finished their hire, they do not have access to the asset again. The hire user uses their username and password to login to Web Studio.

The Hire Management feature is accessible under the “Tools” menu:



Hire Management feature will be displayed as follows:

Customers: create, edit, and delete hire customers

Users: hire users that can access assigned assets

Assets: assign or unassign assets that hire users can access

Notes: add notes for hire customer that is only visible to you

The screenshot shows the Hire Management interface. On the left, a 'Customers' panel is highlighted with a blue box and an arrow pointing to the first callout. The main area has tabs for 'Users', 'Assets', and 'Notes', each with an arrow pointing to its respective callout. The 'Users' tab is active, showing a table of users.


	Edit	Del...	Opts	Username	Email	Phone
1			Opts	test_user1	test@bartco.com.au	1300306106

14.1 Add Hire Customer

- i. Select Add Customer



- ii. Add details of the hire customer and the duration of their hire/use

A screenshot of a dialog box titled "Add new customer" with a close button (X) in the top right corner. It contains three input fields: "Customer Name:" with the text "Hire Customer", "Begin date:" with the date "01/07/2021", and "Expiry date:" with the date "01/08/2021". At the bottom are two buttons: "OK" and "Cancel (ESC)".

- iii. Click OK

- iv. Hire customer will be added in the list




14.2 Add User(s) to Hire Customer


After the hire customer has been added, create new user(s) to the hire customer.

Note: For security purposes it is a good idea for each user to have their own username and password.

A temporary password will be automatically generated and emailed to the hire user.




The hire users can then be managed in Users list:



14.3 Add Asset(s) to Hire Customer


Assign the asset(s) that the users of the hire customer will get access to:



Note: Multiple assets can be assigned to Hire customer.

The hire user can then be given the newly created username and password and be advised to change their password on their first login. They will be responsible for what is displayed on the asset under their login.

When the asset on hire, it will be displayed on the Asset's status icons:



-  Asset is currently on hire to HIRE-CUSTOMER-NAME
-  Asset is hired to HIRE-CUSTOMER-NAME and hire duration is inactive
-  Asset is available to hire
-  No permission to hire asset

15. Troubleshooting

When the asset doesn't communicate on Web Studio with the following error:

 Asset: BARTCO test board (174433)
Error: Cannot connect to asset

POSSIBLE CAUSE	POSSIBLE SOLUTION
Asset out of mobile phone coverage	Move asset to better coverage
Sim card not inserted properly	Check sim card orientation (Reset power after re-positioning sim)
Modem Failure	Contact Bartco
Electrical	Check fuses and battery level

Please contact Bartco's technical support on 1300 306 106 or service@bartco.com.au for any technical assistance.